

Quick Start Guide



www.sar-tick.com

This product meets applicable national SAR limits of 1.6 W/kg. The specific maximum SAR values can be found on page 18 of this user guide.

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 1.0 cm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.

The mobile phone is in compliance with the requirement of EN 60950-1: 2006 amendment A12: 2011. There will appear a warning box when the volume level is over 4. If the user selects left soft key in the warning box, the volume can be increased and the phone will repeat the acknowledgement more than once every 20h of cumulative listening time.




PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.



ALCATEL
onetouch

English - CJB1CB3ALAAA



- 1 Left soft key
- 2 Call logs (idle screen)
Send call
- 3 Voice mail (long key-press)
- 4 Lock Key (long press *0# key)
- 5 Right soft key
- 6 Power on/Power off
End call
- 7 Silent mode
- 8 Navigation key :
Menu/Confirm an option
- 9 Increase volume ▲
Decrease volume ▼
New SMS
- 0 Alarm ▶

1.1 Keys

- Navigation key
Confirm an option (press the middle of the key)
- Send call
Access to call log (idle screen)
- Power on/off the handset (long press)
End call
Return to idle
- Left soft key
- Right soft key
- Dial the voice mail number (long press)
- From Idle screen
- Press: enter zero
- Press and hold: input +, "+" are used for dialing an international call.
- In Edit mode:
- Long Press: input 0 (add numbers)
- From Idle screen
- Press: input *
- Long press: lock keypad
In Edit mode:
- Press: change input methods
- Long press: change writing language
- From Idle screen
- Press: input #
- Press and hold: activate/deactivate silent mode
In Edit mode:
- Press: input space
- Long press: access the Symbols table

1.2 Idle screen icons

- Battery charge level.
- Silent mode: your phone neither rings, beeps nor vibrates.
- Flight mode.
- Headset connected.
- Alarm clock programmed.
- Missed calls.
- Level of network reception.
- Unread SMS.
- Message full.
- Call divert.

2 Getting started

2.1 Set up

Removing and installing the back cover




Removing and installing the battery



Inserting and removing SIM



Charging the battery



Connect the battery charger to your phone and outlet respectively.

- The charging may take about 20 minutes to start if the battery is flat.
- Be careful not to force the plug into the socket.
- Make sure the battery is correctly inserted before connecting the charger.
- The outlet must be near to the phone and easily accessible (avoid electric extension cables).
- When using your telephone for the first time, charge the battery fully (approximately 3 hours). You are advised to fully charge the battery ().
- To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; reduce the backlight time, etc.



The charge is complete when the animation stops.

2.2 Power on your phone

Hold down the key until the phone powers on.

2.3 Power off your phone

Hold down the key from the idle screen.

3 Calls.....

3.1 Making a call

Dial the desired number, press the key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the key. To hang up the call, press the key.

Making an emergency call

If your phone is covered by the network, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

3.2 Calling your Voice mail⁽¹⁾

You can see SIM voice mail in this menu.

3.3 Receiving a call

When you receive an incoming call, press the key to talk and then hang up using the key.

3.4 Available functions during the call

During a call, you can use your directory, your calendar, text messages, etc. without hanging up or dropping the call.

⁽¹⁾ Contact your network operator to check service availability.

4 FM radio.....

Your phone is equipped with a radio. You can use the application as a traditional radio with saved channels. In FM radio interface, press to play/pause the playing process of the current channel, press and to tune volume.

5 Call logs

You can access your call history by pressing from the idle screen, or press the key and select the icon from the menu. In this menu, you will see all call history.

6 Alarm

Your mobile phone has a built-in alarm clock with snooze feature.

7 Tools

7.1 Calculator

Press the up, down, left, right and OK key to select +, -, ×, ÷, x, and = respectively.
Press to clear the figure.

7.2 Calendar

Once you enter this menu, there is a monthly-view calendar for you to view the date; you can go to any day you want.

7.3 Convert

Converter support weight conversion and length conversion.

7.4 Torch

Turn on/off the torch whenever you need to. In idle screen, press and hold 5 key to activate/deactivate the torch light.

7.5 Call Filter

You can create blacklist/whitelist through this function.

7.6 Services

STK service is the tool kit of SIM card. This phone supports the service function. The specific items depend on SIM card and network. Service menu will be automatically added to the phone menu when supported by network and SIM card.

8 Message.....

From the main menu select "Message" to create text message. You can type a message send it to a recipient in the SIM card directory. While writing a message, select "Options" to access all the messaging options.



Specific letters (accent) will increase the size of the SMS, this may cause multiple SMS to be sent to your recipient.

9 Profiles

The mobile phone provides multiple user profiles, so that you can customise some settings to adapt to the specific events and environments.

10 Games.....

This function enables you to enjoy simple games.

11 Contacts

11.1 Consulting your contacts

You can access your contacts by pressing from the idle screen, or press the key and select the icon from the menu. In this menu, you will see all contacts.

11.2 Add contact

Select the menu "New contact" then save it to "Phone", "SIM" as you like.

12 Settings.....

From the main menu, select the menu and select the function of your choice in order to customise your telephone: Phone settings, Call settings, Network, Security, Restore factory settings.

13 Input mode

This mode allows you to type a text by choosing a letter or a sequence of characters associated with a key. Press the key several times until the desired letter is highlighted. When you release the key the highlighted character is inserted into the text.

ALCATEL is a trademark of Alcatel-Lucent and is used under license by TCL Communication Ltd.
© Copyright 2015 TCL Communication Ltd All rights reserved
TCL Communication Ltd reserves the right to alter material or technical specification without prior notice.

